Infant Swing (04-0032)

1. Insert the yellow T-bar into the hole at the front of the swing. If you need to disengage the T-bar you can squeeze the 2 tabs together under the seat while pulling the T-bar up. Under normal conditions the T-bar is always snapped into the seat before the child is placed into the seat.





FOR RESIDENTIAL USE ONLY

SUGGESTED FOR CHILDREN AGES 7 MONTHS TO 3 YEARS

Seat Buckle Adjustment

- 2. Depress the tabs that hold the male end of the buckle to the female end.
- 3: Adjust the length of the belt by sliding the belt through the male portion of the buckle.






Attaching Swing to Swing Hangers


- 4. There are many different ways to connect the "End Eyes" on the end of the ropes to swing hangers that exist on your swing set or custom swing. Always follow the manufacturer's directions on how to attach the swing to the swing hangers.
- 5. Safety comes first when swinging. Always obey the safety rules when swinging and when walking around a swing set. We have included a Safety Tips guide on page 5.

Infant Swing Weight Limit: 35 lbs



Infant Swing Height Adjustment and Strapping In

- 6. Move the Plastic Eye Plate up to move the swing up. Move the Plastic Eye Plate down to move the swing down.
- 7: Stand beside the swing and push down on the T-bar and the back of the swing at the same time. The swing should end up in a position tilted as shown below.
- 8: After your child is in the swing insert the male end of the buckle into the female end. Then adjust the belt as required to fit your child. Make sure the belt is not twisted and that the free end of the belt is on the outside.



SAFETY TIPS FOR SWINGS

- On-site adult supervision is required.
- Teach children not to walk close to, in front of, behind, or between **moving swings** or other moving playground equipment.
- Teach children to sit in and never stand on swings. (Exception to this rule is a product called "Stand -N- Swing")
- Teach children not to twist the chains and ropes and not to loop them over the swing beam, since this may reduce the strength of the chain or rope.
- Teach children not to jump from swings that are in motion.
- Teach children not to push empty seats. The seat may hit them and cause injury.
- Teach children to sit in the center of swings with their full weight on the seats.
- Teach children not to use the equipment in a manner other than intended.
- Parents should have the children dress appropriately with well-fitting shoes. Loose clothing such as scarves and ponchos should not be worn. Always take off, tie up or tuck in cords and drawstrings on children's clothing. These things can get caught on playground equipment and strangle a child.
- Teach children not to climb when the equipment is wet.
- Teach children not to attach items to the playground equipment that are not specifically designed for use with the equipment, such as, but not limited to, jump ropes, clothesline, pet leashes, cables and chains, as they may cause a strangulation hazard.
- Teach children to never wrap their legs around swing chain.
- Teach children to never slide down the swing chain.
- Protective surfacing under swings is recommended. "To and Fro" swings should have a fall zone extending a minimum of 6' from the outer edge of the support structure on each side. The "fall zone" in front and back of the swing should extend out a minimum distance of twice the height of the swing as measured from the ground to the top of the swing support structure. Swings should have a minimum of 8 inches between them. (ASTM F-1148-12) The bottom of a swing should not be less than 8 inches above the protective surfacing material. (ASTM F-1148-12) Home Playground Safety Specification ASTM F-1148-12 may be purchased online. A guide for Public Playground Safety from the U.S. Consumer Product Safety Commission may be downloaded at:

http://www.cpsc.gov//PageFiles/122149/325.pdf

• A fall zone for a "tire swing" capable of unlimited lateral motion will be equal to a minimum horizontal distance of Y + 72 in. in all directions from the pivot point of the swing. Y equals the vertical distance between the pivot point and the top of the tire swing. Protective surfacing is recommended in the fall zone for tire swings.

If any of the following conditions are noted they should be removed, corrected or repaired immediately to prevent injuries:

- Hardware that is loose, worn, or those that have protrusions or projections.
- Scattered debris, litter, rocks or tree roots.
- Missing or damaged equipment components, such as swing seats.
- Remove plastic swing seats and take indoors (or do not use) when the temperature drops below 32° F.
- Oil all metallic moving parts monthly during the usage period.
- Check swing seats, ropes, cables and chains monthly during usage season for evidence of deterioration.

Replacement should be made of any swing seat that has developed cracks in the plastic seats or has exposed metal in the edges of the swing seat. If there are already exposed metal inserts on the edge of the seat, immediately remove the seat and chains to prevent serious injury. Ropes, cables and chains should be removed and replaced if excessive wear is found.

5