37" Metal Safety Handles (Pair) 08-0002 2 x 4 Wrap

1. Place the "U" shaped ends over a vertical board. The board may be slightly inclined forward from vertical. The board must be 1-3/8" thick maximum thickness for a snug fit. If you use standard 2 x 4 or 2 x 6 lumber, then you will have to sand down the areas where the "U" shaped ends bolt on.

!WARNING! METAL SAFETY HANDLES ARE NOT FOR OVERHEAD USE AND ARE NOT TO SUPPORT THE FULL OR PARTIAL HANGING WEIGHT OF A PERSON OR OBJECT. DO NOT ATTACH CHAINS, PET LEASHES, ROPES OR ANY OTHER OBJECTS TO THE METAL SAFETY HANDLES.

2. Attach the "U" shaped ends to the board with a #14 x 1-1/4" pan head screw and a 1/4" washer in each of the square holes. (HARDWARE NOT INCLUDED)

