


BUOY BALL WITH CHAIN (04-0011)

- 1: ATTACH ONE SPRING CLIP TO EACH S-HOOK ON THE TRAPEZE BAR.
- 2: ATTACH CHAIN ENDS TO SPRING CLIPS.
- 3: ADJUST HEIGHT AS NEEDED.




FOR RESIDENTIAL USE ONLY
FOR CHILDREN AGES 3-11

SEE INFLATION INSTRUCTIONS ON BACK OF THIS PAGE.

INFLATION INSTRUCTIONS

Air needles are used to inflate basketballs, soccer balls, footballs, kick balls and our punching ball/buoy ball on your play set. An air needle is not included. You may purchase one of these air needles at any department or sporting goods store.



Air Needle

- 1) Moisten the air needle with water.
- 2) Place the locking end of your hand operated air pump or electric air pump onto the threaded end of the air needle and lock it into place.
- 3) Place the air needle into the small valve in the Punching Ball or Buoy Ball.
- 4) Inflate the Punching Ball/Buoy Ball until it is firm like a kick ball. Do not over-inflate. A pressure of 3 to 6 p.s.i. should be sufficient.
- 5) Turn off the electric air pump if you are using one. Remove the air needle from the Punching Ball/Buoy Ball. Remove the locking end of the air pump from the air needle.
- 6) Store the air needle in a safe place away from young children as this could pose a choking hazard.
- 7) After a period of time if the Punching Ball/Buoy Ball loses air pressure, re-inflate it as required.