

SPRING CLIP (11-4003)

THIS PRODUCT IS FOR RESIDENTIAL USE ONLY ON CHILDREN'S SWINGSETS. THIS PRODUCT IS RECOMMENDED FOR CHILDREN FROM AGES 3-11.

DO NOT EXCEED THE MAXIMUM LOAD OF 200 LBS PER CLIP OR INJURY COULD OCCUR. THE SPRING CLIPS ARE MEANT FOR USE IN PAIRS TO SUPPORT A SWING BELT AT TWO ATTACHMENT POINTS FROM A SWING BEAM. THE SWING BEAM SHOULD BE RATED ACCORDINGLY FOR THE LOAD THAT WILL BE PLACED UPON IT. THE SELLER OR MANUFACTURER WILL NOT BE HELD LIABLE FOR ANY ACCIDENTS OR MISUSE OF THIS PRODUCT. THIS PRODUCT IS INTENDED FOR USE WITH SWINGS AND SWING ACCESSORIES ONLY. DO NOT HANG ANY OTHER OBJECTS FROM THE SPRING CLIPS.

DEPICTED BELOW IS A TYPICAL "CLOSED LOOP" SWING HANGER WHICH WOULD BE ATTACHED TO A BEAM SUFFICIENT TO SUPPORT THE LOAD FROM A SWING BELT, MULTIPLE SWING BELTS OR OTHER SWING ACCESSORIES.

1: PLACE THE SPRING CLIP ONTO THE "CLOSED LOOP" SWING HANGER BY DEPRESSING THE SIDE AND PLACING THE HOOK THROUGH THE LOOP OF THE SWING HANGER.

2: SNAP THE CHAIN FROM THE SWING BELT OR OTHER SWING ACCESSORY ONTO THE SPRING CLIP BY DEPRESSING THE SIDE OF THE SPRING CLIP AND PLACING A CHAIN LINK ONTO THE HOOK OF THE SPRING CLIP.

3: ADJUST HEIGHT OF THE SWING BELT OR OTHER SWING ACCESSORY UP OR DOWN BY CLIPPING THE SPRING CLIP ON HIGHER OR LOWER CHAIN LINKS.

